

Remind.U reminds you

A simply Bluetooth Reminder that attaches to your backpack, handbag or key-chain, and connects to your phone wirelessly; it works with any Bluetooth enabled mobile phones, gives a timely alert when your mobile phone is away from Remind.U device.

Specification

Bluetooth Class-2 standard, alert range within a 30-foot radius
Build-in rechargeable Li-poly battery, standard USB 5V charging.

Getting Start

Please charge the battery power for at least 2 hours before your first time usage; upon recharging completed, the Red LED will off automatically.

Press and hold 5 seconds to turn on the device, and the same way to power off the device.

Status Indicator

Status	LED Lights	Buzzer
ON/OFF	Red & Blue LED flash once.	Single Beep once
Waiting	Blue LED flashes rapidly	No
Connected	Blue LED flashes slowly and intermittently.	No
Disconnected	Red and Blue LED flash rapidly, continue for 10 sec. △ Press on/off button once to off the alert situation.	Double Beep repeatedly
Low battery	Red LED flashes rapidly, and it lasts for 20 sec then power off.	Triple Beep once
Charging	Red LED stays power on till charging completed.	No

About Bluetooth Setting

Turn on Remind.U device also the Bluetooth function of your mobile phone, search for a device named “**Remind.U**” and then click to establish connection. Some phones may request PIN code, please enter “**0000**” to complete the devices pairing for the very first time, and afterwards require no more pairing.

Safety Caution

Please use this device under normal ambient temperature, and should stay away from high heat sources, high voltage equipment, as well as to avoid long time of exposure under strong sunlight.

More advanced features and mobile interactive apps are available for Smartphone.